




Refer to page 11 - 13 in the SMT-IAQ3 manual for advanced programming

