

MODEL	FUNCTION	SW 1 OFF / ON	SW 2 OFF / ON	SW 3 OFF / ON	SW 4 OFF / ON	SW 5 OFF / ON	SW 6 OFF / ON	SW 7 OFF / ON	SW 8 OFF / ON
DSL-100	HEAT ONLY	4 MIN / 2MIN MINIMUM ON TIME	Keyboard UNLOCK / LOCK	NO SWITCH	NO SWITCH	NO SWITCH	NO SWITCH	NO SWITCH	NO SWITCH
DSL-150	COOL ONLY	4 MIN / 2MIN MINIMUM ON TIME	Keyboard UNLOCK / LOCK	NO SWITCH	NO SWITCH	NO SWITCH	NO SWITCH	NO SWITCH	NO SWITCH
DSL-200	MAN HEAT/COOL	4 MIN / 2MIN MINIMUM ON TIME	Keyboard UNLOCK / LOCK	FAN W-HEAT/ / FAN W-PLENUM	NO SWITCH	NO SWITCH	NO SWITCH	NO SWITCH	NO SWITCH
DSL-200A	AUTO HEAT/COOL	4 MIN / 2MIN MINIMUM ON TIME	Keyboard UNLOCK / LOCK	FAN W-HEAT/ / FAN W-PLENUM	NO SWITCH	NO SWITCH	NO SWITCH	NO SWITCH	NO SWITCH
DSL-300	AUTO HEAT/COOL	4 MIN / 2MIN MINIMUM ON TIME	Keyboard UNLOCK / LOCK	FAN W-HEAT/ / FAN W-PLENUM	NO SWITCH	NO SWITCH	NO SWITCH	NO SWITCH	NO SWITCH
DSL-400	1 STAGE HEAT PUMP	4 MIN / 2MIN MINIMUM ON TIME	Keyboard UNLOCK / LOCK	NO SWITCH	NO SWITCH	NO SWITCH	NO SWITCH	NO SWITCH	NO SWITCH
DSL-450	1 STAGE HEAT PUMP COMPLETE/W AUX HT	4 MIN / 2MIN MINIMUM ON TIME	Keyboard UNLOCK / LOCK	NOT APPLICABLE	NOT APPLICABLE	L1 ICON / L1 ICON FILTER	L2 ICON / L2 ICON WRENCH	NO SWITCH	NO SWITCH
DSL-600	2 STAGE HEAT PUMP	NORMAL/ADD.ON HE AT PUMP	NOT APPLICABLE	4 MIN / 2MIN MINIMUM ON TIME	Keyboard UNLOCK / LOCK	NOT APPLICABLE LEAVE OFF	Single st./Multi st	L1 ICON / L1 ICON FILTER	L2 ICON / L2 ICON WRENCH
DSL-700	2 HEAT + 2 COOL	4 MIN / 2MIN MINIMUM ON TIME	Keyboard UNLOCK / LOCK	FAN W-HEAT/ / FAN W-PLENUM	Single st/Multi st	L1 ICON / L1 ICON FILTER	L2 ICON / L2 ICON WRENCH	NO SWITCH	NO SWITCH
SC-1	PROGRAMMABLE COOL ONLY	4 MIN / 2MIN MINIMUM ON TIME	Keyboard UNLOCK / LOCK	NORMAL / ADD.ON HEAT PUMP	NO SWITCH	NO SWITCH	NO SWITCH	NO SWITCH	NO SWITCH
SK-3	PROGRAMMABLE HEAT / COOL	4 MIN / 2MIN MINIMUM ON TIME	Keyboard UNLOCK / LOCK	FAN W-HEAT/ /FAN W-PLENUM	NO SWITCH	NO SWITCH	NO SWITCH	NO SWITCH	NO SWITCH
SHP-1	PROGRAMMABLE 1 STAGE HEAT PUMP	4 MIN / 2MIN MINIMUM ON TIME	Keyboard UNLOCK / LOCK	NOT APPLICABLE	NOT APPLICABLE	L1 ICON / L1 ICON FILTER	L2 ICON / L2 ICON WRENCH	NO SWITCH	NO SWITCH
SHC-7	PROGRAMMABLE COMMERCIAL SINGLE HEAT / COOL	4 Event / 2 Event /DAY /DAY	NO SMART / SMART FAN FAN	4 MIN / 2MIN MINIMUM ON TIME	Keyboard UNLOCK / LOCK	FAN W-HEAT/ / FAN W-PLENUM	NO SWITCH	NO SWITCH	NO SWITCH
SHP-2	PROGRAMMABLE COMMERCIAL TWO STAGE HEAT PUMP WITH AUX HT.	4 Event / 2 Event /DAY /DAY	NO SMART / SMART FAN FAN	4 MIN / 2MIN MINIMUM ON TIME	Keyboard UNLOCK / LOCK	NORMAL / ADD.ON HEAT PUMP	Single st./Multi st.	L1 ICON / L1 ICON FILTER	L2 ICON / L2 ICON WRENCH
SMS-1	PROGRAMMABLE COMMERCIAL 2 STAGE HEAT 2, STAGE COOL	4 Event / 2 Event /DAY /DAY	NO SMART / SMART FAN FAN	4 MIN / 2MIN MINIMUM ON TIME	Keyboard UNLOCK / LOCK	FAN W-HEAT/ / FAN W-PLENUM	Single st./Multi st.	L1 ICON / L1 ICON FILTER	L2 ICON / L2 ICON WRENCH

enerstat Slimline Quick Reference Guide

enerstat Australia Pty Ltd, 37 Benwerrin Drive, Burwood East, Vic. 3151 ph. 0398035744 fax 0398037585

visit our home page on <http://www.enerstat.com.au>

INTERNATIONAL TERMINAL DESIGNATORS

R = INDEPENDENT CONTROL VOLTAGE
W = CONTROL VOLTAGE FOR HEAT
W2 = CONTROL VOLTAGE FOR HEAT 2
O = ENERGISED IN COOLING MODE
RC = CONTROL VOLTAGE FOR COOLING
Y = CONTROL VOLTAGE FOR COOL
Y2 = CONTROL VOLTAGE FOR COOL 2
B = ENERGISED IN HEATING MODE

RS1 - RS+V - RS2 = USED TO CONNECT REMOTE SENSORS BOTH OUTDOOR AND INDOOR TYPE.

G = INDOOR FAN CONTROL SIGNAL
W1 = CONTROL VOLTAGE FOR HEAT 1
24Vac(C) = 24 VOLT AC COMMON
OCC = ENERGISES IN THE OCCUPIED MODE, DE-ENERGISE IN THE UNOCCUPIED MODE
LED1 AND LED 2 = FREE LIGHTS FOR STATUS OF FUNCTION INDICATION, ENERGISED WITH 24VOLT ac.
RH = CONTROL VOLTAGE FOR HEATING
Y1 = CONTROL VOLTAGE FOR COOL 1
24Vac = 24 VOLT AC HOT FROM X-FORMER