



Under "System Type Selection" select "Conventional 1H with fan"

ALL CARE AND DILIGENCE HAS BEEN TAKEN IN THE PREPARATION OF THIS INTERFACE DIAGRAM. **SMART TEMP AUSTRALIA PTY LTD** WILL ONLY BE RESPONSIBLE FOR DAMAGE CAUSED TO THE SMART TEMP PRODUCT, AND ONLY IF IT HAD BEEN CORRECTLY APPLIED IN ACCORDANCE WITH THE MANUFACTURES INSTRUCTIONS. IT IS THE DEALER / CONTRACTORS SOLE RESPONSIBILITY TO ENSURE CORRECT OPERATION OF THE MAJOR EQUIPMENT IS MAINTAINED.

| | | |
|---|--------------------|--|
| | | <h2>Installation Drawing</h2> |
| Drawing Revision History | | Drawing Name SMT-450 Flexistat wired to Braemar with 24V relays for heat & Fan |
| | | <small>All care has been taken in the preparation of this drawing however Smart Temp Australia accept no responsibility for damage that may be caused by using this information. This is a guide only.</small> |
| 15-05-2025 | REV 1.0 By: John K | |
| Unit 20, 1488 Ferntree Gully Road Knoxfield Vic 3180 Ph: (03) 9763 0094 Fax: (03) 9763 0098 www.themostat.com.au | | |