



Typical Gas Heat / Ad on Cooling



SMT-710 Dip Switch Settings

Switch	Function	Setting
1	Fan Speeds	OFF
2	Equipment Type	OFF
3	HP/HC Mode	OFF
4	Not Used	
5	Comp Delay	ON
6	Not Used	
7	Ventilation Mode	ON
8	Zone Enable	ON

SMT-710 Installer Options
(Refer to installer manual for advanced settings)

Option 13 = 2 (W2 stage 2 heat)

ALL CARE AND DILIGENCE HAS BEEN TAKEN IN THE PREPARATION OF THIS INTERFACE DIAGRAM. SMART TEMP AUSTRALIA PTY LTD WILL ONLY BE RESPONSIBLE FOR DAMAGE CAUSED TO THE SMART TEMP PRODUCT, AND ONLY IF IT HAD BEEN CORRECTLY APPLIED IN ACCORDANCE WITH THE MANUFACTURERS INSTRUCTIONS. IT IS THE DEALER / CONTRACTORS SOLE RESPONSIBILITY TO ENSURE CORRECT OPERATION OF THE MAJOR EQUIPMENT IS MAINTAINED.

		<h2>Installation Drawing</h2>	
Drawing Revision History			Drawing Name SMT-710 - 2 Stage Gas Heat with cooling and 2 Zones wired
01-07-2024	REV 1.0	By: John K	<small>All care has been taken in the preparation of this drawing however Smart Temp Australia accept no responsibility for damage that may be caused by using this information. This is a guide only.</small>
Unit 20, 1488 Ferntree Gully Road Knoxfield Vic 3180			Ph:(03) 9763 0094 www.themostat.com.au