


Enter the SMT-450 Installer menu (PIN is 0021)
Under "System Type Selection" choose the "Others" option,
then select "Conventional 1H no fan"

ALL CARE AND DILIGENCE HAS BEEN TAKEN IN THE PREPARATION OF THIS INTERFACE DIAGRAM. **SMART TEMP AUSTRALIA PTY LTD** WILL ONLY BE RESPONSIBLE FOR DAMAGE CAUSED TO THE SMART TEMP PRODUCT, AND ONLY IF IT HAD BEEN CORRECTLY APPLIED IN ACCORDANCE WITH THE MANUFACTURES INSTRUCTIONS. IT IS THE DEALER / CONTRACTORS SOLE RESPONSIBILITY TO ENSURE CORRECT OPERATION OF THE MAJOR EQUIPMENT IS MAINTAINED.

			Installation Drawing	
Drawing Revision History			Drawing Name	
			SMT-450 with an SMT-2W5, SP1 and SZ-PS wired to 240V Boiler/Heater	
26-05-2026			REV 1.0 By: John K	
Unit 20, 1488 Ferntree Gully Road Knoxfield Vic 3180			Ph: (03) 9763 0094 www.thermostat.com.au Fax: (03) 9763 0098	