

RH-RC Jumper Switch = ON (Factory Default)
Advance settings via APP
Set System Type to Heat Pump = HP-1H1C (3 Speed Fan)
Set O/B Reversing Valve to B (Heating)



ALL CARE AND DILIGENCE HAS BEEN TAKEN IN THE PREPARATION OF THIS INTERFACE DIAGRAM. ***SMART TEMP AUSTRALIA PTY LTD*** WILL ONLY BE RESPONSIBLE FOR DAMAGE CAUSED TO THE SMART TEMP PRODUCT, AND ONLY IF IT HAD BEEN CORRECTLY APPLIED IN ACCORDANCE WITH THE MANUFACTURES INSTRUCTIONS.
IT IS THE DEALER / CONTRACTORS SOLE RESPONSIBLITY TO ENSURE CORRECT OPERATION OF THE MAJOR EQUIPMENT IS MAINTAINED.

Installation Drawing

Drawing Revision History		
19-07-2024	REV 1.0	By: John K

Drawing Name

SMT-450 wired to a 1 Stage Heat Pump with 3 Fan Speed

All care has been taken in the preparation of this drawing however Smart Temp Australia accept no responsibility for damage that may be caused by using this information. This is a guide only.

Unit 20, 1488 Ferntree Gully Road Knoxfield Vic 3180 Ph:(03) 9763 0094 www.thermostat.com.au