



RH-RC Jumper Switch = ON (Factory Default)


Advance settings via Settings or APP
Set System Type to Conventional = 1H1C




Sender module Typical Colour Codes

Mark	Colour	Typical Function
1	Green	G - Fan
2	Yellow	Y1 - 1st Stage Cool
3	White	W1 - 1st Stage Heat or Reversing Valve
4	Purple	Y2 - 2nd Stage Cool
5	Brown	W2 - 2nd Stage Heat or Aux / Emergency Heat
24R	Red	24 VOLT (HOT)
24C	Black	24 VOLT (COMMON)

Relay Receiver Module





Installation Drawing

Drawing Revision History		Drawing Name
		SMT-450 wired to a Gas Heater with Add on Cooling using an SMT-2W5 2 wire Interface
All care has been taken in the preparation of this drawing however Smart Temp Australia accept no responsibility for damage that may be caused by using this information. This is a guide only.		
22/07/24	John K	
U20, 1488 Ferntree Gully rd Knoxfield Vic 3180		Ph:(03) 9763 0094 WWW.thermostat.com.au